



**Ultra Corporation Pty Ltd**

PO Box 1256, Slacks Creek Qld 4127.

Phone: (07) 3442 2507 Fax: (07) 3442 2599

eMail: [service@ultra-corporation.com.au](mailto:service@ultra-corporation.com.au) Web: <http://www.ultra-corporation.com.au>

## INSTALLATION OF ULTRA DRAIN 60

Please read the following, as this will assist you in the installation of **ULTRA DRAIN 60**.

There are two simple methods:

### Method 1:

1. Place wooden pegs at 600mm intervals set to the correct level.
2. Nail through the **ULTRA DRAIN 60** base to secure it in place.
3. Concrete to the desired level, ensuring the polyformer insert is in place.

### Method 2:

1. Use a concrete or plaster mix to haunch the **ULTRA DRAIN 60** in place to the correct level.
2. Concrete to the desired level, ensuring the polyformer insert is in place.

To further secure the **ULTRA DRAIN 60** we recommend drilling and putting a 300mm piece of reinforcing bar (10mm or 12mm) through the upper part of the drain at 1 metre intervals. This will prevent the drain 'floating' when the concrete is poured.

Ensure that you do not collapse the top of the **ULTRA DRAIN 60** inwards when concreting, as this will make fitting the alloy top difficult. Always insert the polyformer into the channel before pouring concrete.

The cleaning section (240mm long) should be put in a central position to make cleaning the drain, when required, a lot easier. It is more convenient to remove a 240mm section than a 2800mm piece.

For optimum cleaning – place cleaning sections at 3 metre intervals.

**Warning:** Clean alloy grating with pH neutral products only.